

12/24V, 20A Solar Charge controller

Image for representation only

Housing Material: ABS/MS/Aluminum

LED Indications:

- Battery charging in progress
- Battery charged
- Load disconnected

Protections:

- Battery reverse polarity
- Open and short circuit
- Over voltage
- Battery deep discharge
- Battery overcharge

Electrical Specifications:

- Load disconnect battery voltage: 11V +/- 0.2V
- Load disconnect battery voltage: 12.5V +/- 0.2V
- Constant charging voltage: 14.5V +/- 0.2V

System Connection sequence:

- Connect Battery
 - Connect solar panel
 - Connect load
- While disconnecting follow the reverse order